

ON-SCREEN DISPLAY

SET UP	
LENS	DC↔ / VIDEO / MANUAL
SHUTTER	FLK / FIXED↔ / MANUAL↔ / AUTO↔
BLC	ON↔ / OFF
AGC	ON↔ / OFF
WHITE BAL	ATW / AWB / FIXED↔ / MANUAL↔
FUNCTION	↔
ADJUST	↔
EXIT	

1. Lens

1.1 DC Drive : brightness adjustable , from 000 to 255
 BRIGHTNESS 000-255

2. Shutter:

2.1 Shutter Fixed: from 1/50 to 1/100,000 selectable
 1/50; 1/120; 1/250 ; 1/500; 1/2,000; 1/5,000; 1/10,000; 1/100,000
 2.2 Shutter Manual:
 SHUTTER M. 000-255

3. BLC (back light compensation):

3.1 BLC on:
 3.1.1 BLC Area: use "up" "down" "enter" choose the BLC adjusted area,
 then press "enter" 2 seconds, clear then reset, or set then exit.

8X8							
ALL CLEAR							
ALL SET							
RETURN							
EXIT							

3.1.2 BLC Ratio: adjustable 00-63

BLC SETUP	
BLC AREA↔	
BLC RATIO	00-63
↔:RETURN	

4. AGC (auto gain control):

4.1 AGC on:
 AGC GAIN 000-255

5. White Balance:

5.1 :AWB Fixed: MODE 1 (normal), MODE 2 (blue),
 MODE 3 (yellow),MODE 4 (green)

5.2 AWB Manual

AWB MANUAL	
RED	000-255
BLUE	000-255
↔:RETURN	

6 Adjust

Contrast	000-255
Sharpness	00-31
CB_Gain	000-255
CR_Gain	000-255
↔:RETURN	

FUNCTION

RETURN	ON↔ / OFF
CAMERA ID	ON↔ / OFF
MIRROR	ON↔ / OFF
DAY NIGHT	B/W↔ / COLOR / AUTO↔
MOTION	On↔ / OFF
PRIVACY	ON↔ / OFF
GAMMA	0.05 / 0.10 / 0.15...0.70
LANGUAGE	ENGLISH / 汉(简) / 汉(繁) / 日 / KOREA
RESET	↔

1. Camera ID

1.1 Camera ID on : use "right" "left" set the camera name. "Enter"
 confirm camera name, "C" cancel the name ↔exit name set.

ID SETUP	
CAMERA ID	↔:C (Cancel)
POSITION↔	
↔:RETURN	

2. Day Night

2.1 Day night Auto:
 2.1.1 You can set the conversion time from one mode to another
 (color to B/W)
 2.1.2 You can set when the camera convert mode, when
 the camera return the first mode

DAY NIGHT AUTO	
DELAY	000-63
START LEVEL	000-255
END LEVEL	000-255
↔:RETURN	

3. Motion (Using this function need other device work together)

AREA↔	
MOTION TH	000-255
MOTION TRACE	ON/OFF
↔:RETURN	

3.1 Motion Area: use "up" "down" "enter" choose the area which will
 be record when something move , then press "enter" several
 second, clear then reset, or set then exit.

8X8							
ALL CLEAR							
ALL SET							
RETURN							
EXIT							

4. Privacy

4.1 Area select: there are 4 area which can't be monitor on screen.
 When area state is on, set the parameter of "left" "right" "top"
 "bottom" to set the area place. Also can using different color to
 mark different area.

AREA SEL	AREA0,1,2,3	
AREA STATE	ON/OFF	000-255
LEFT		000-255
RIGHT		000-255
TOP		000-255
BOTTOM		000-255
COLOR		000-015
RETURN		

5. Gamma preference : from user (0), 0.05, 0.15, 0.20, 0.25... .. to 1.0